SAWA UNIVERSITY

اساسيات الفيزياء الشعاعية/ الكورس الاول

GENERATING THE TUBE VOLTAGE



Sawa University	جامعـــــــة ســـــــاوة الاهلية
College of health and medical techniques	كليـــــة التقنيـــات الصحيـة والطبيـة
Department of Radiology Tech.	قسم تقنيات الاشعة والسونار
Second Stage	المرحلـــــــــــة الثانية

الجانب النظري محاضرة رقم (1)

Theoretical Lecture No. (1)

تدريسي المادة : م.م. احمد عكاب شراد

(X-RAY PRODUCTION)

- X-ray production requires three essentials:

1. Source of electrons (filament heating).
2. Acceleration of electrons (tube voltage, kVp).
3. Rapid deceleration at the target (anode).

- Efficiency: only <1% of electron energy → x-rays, >99% → heat.
- Thus, careful control of voltage, current, and time is critical for quality imaging and equipment safety.

(GENERATING TUBE VOLTAGE (KVP))

- Definition: The potential difference applied between the cathode and anode of the x-ray tube.
- Determines:

- Electron speed (kinetic energy).Maximum photon energy (keV).
- Formula: $E_{max}(keV) = e \times v_{tube}$

- Example: 120 kVp → photons with max energy of 120 keV.
- Higher voltage = shorter wavelength, higher penetration power.

(HIGH-VOLTAGE SUPPLY)

- Uses step-up transformer (converts ~220 V → 30–150 kVp).
- Rectification circuits ensure unidirectional current:
  - Single-phase (obsolete, 100% ripple).
  - Three-phase 6-pulse & 12-pulse (reduced ripple, improved efficiency).
  - High-frequency generators (modern standard, <1% ripple).
- Ripple affects photon output: less ripple = more consistent x-ray beam.

(EFFECT OF KVP ON IMAGE & DOSE)

- Higher kVp:
  - More penetrating X-rays.
  - Lower image contrast (longer grayscale).
  - Reduced patient dose for the same image receptor exposure.
- Lower kVp:
  - Higher contrast (shorter grayscale).
  - Increased patient dose due to absorption.
- Clinical example:
  - Chest x-ray → 110–125 kVp (needs penetration).
  - Extremities → 50–65 kVp (requires contrast).

(EXPOSURE TIME)

- **Definition:** Duration for which electrons cross tube = time x-rays are produced.
- Controlled by electronic timers (modern).
- Expressed in milliseconds (ms).
- Directly influences total radiation output:

$$mAs = mA \times s$$

- Key role: minimizing motion blur (heart, lungs, pediatrics).

(EXPOSURE TIMER TYPES)

1. **Mechanical Timers** – old, inaccurate, only seconds.
2. **Synchronous Timers** – linked to AC supply cycles (60 Hz → 1/60s resolution).
3. **Electronic Timers** – most common, accurate to <1 ms.
4. **AEC (Automatic Exposure Control):** stops exposure once the image receptor receives enough radiation → dose optimization.

(FALLING LOAD PRINCIPLE)

- A generator method where exposure begins with maximum tube current (mA), which gradually decreases as the tube heats up.
- Benefits:

- Shortest possible exposure time.
- Maintains constant kVp.
- Prevents anode overheating.

- Applications: angiography, CT, fluoroscopy, cardiac imaging.

(FALLING LOAD CURVE VS. FIXED LOAD)

- Fixed load: constant mA throughout exposure → longer exposure time.
- Falling load: mA decreases → faster exposure.
- Visual analogy: draining water from a tank by opening the valve wide at first, then narrowing as the tank empties.
- Advantage: allows imaging of moving structures (e.g., blood vessels) without blur.

(FILAMENT VOLTAGE)

- Filament = tungsten coil heated by low voltage (~6–12 V, 3–5 A).
- Heating → thermionic emission: electrons “boiled off” the cathode.
- Forms electron cloud (space charge).
- Tube current (mA) directly depends on filament temperature.

(RELATIONSHIP BETWEEN PARAMETERS)

- kVp → controls photon energy (quality).
- mA → controls photon quantity (intensity).
- Time (s) → determines total exposure.
- mAs = mA × s → controls image receptor exposure.
- Example:

- 100 mA × 0.5 s = 50 mAs.
- 200 mA × 0.25 s = 50 mAs (same dose, less motion).

(HEAT AND TUBE LOADING)

- 99% energy → heat, only 1% → x-rays.
- Filament overheating = burnout risk.
- The tube housing features oil and cooling fans.
- Falling load prevents instant overload by distributing heat across exposure.
- Heat Units (HU):

$$HU = kVp \times mA \times s \times phase\ factor$$

(HEAT AND TUBE LOADING)

- 99% energy → heat, only 1% → x-rays.
- Filament overheating = burnout risk.
- The tube housing features oil and cooling fans.
- Falling load prevents instant overload by distributing heat across exposure.
- Heat Units (HU):

$$HU = kVp \times mA \times s \times phase\ factor$$

(SUMMARY)

- **Tube voltage**: controls penetration & contrast.
- **Exposure timing**: balances dose & motion blur.
- **Falling load:** optimizes exposure time & tube protection.
- **Filament voltage**: regulates electron supply → x-ray output.
- Integration of all ensures quality diagnostic images with minimum patient risk.

QUIZ

Q 1: WHICH COMPONENT IN THE X-RAY CIRCUIT PRIMARILY DETERMINES THE TUBE VOLTAGE (KVP)?

A. AUTOTRANSFORMER B. RECTIFIER C. FILAMENT TRANSFORMER D. EXPOSURE TIMER.

Q2: THE PRIMARY PURPOSE OF THE EXPOSURE TIMER IN RADIOGRAPHIC EQUIPMENT IS TO:

A. CONTROL THE INTENSITY OF X-RAYS B. LIMIT THE EXPOSURE DURATION TO AVOID PATIENT OVEREXPOSURE

C. REDUCE THE FILAMENT HEATING D. INCREASE THE ANODE ROTATION SPEED

Q 3: FALLING LOAD TECHNIQUE IS MAINLY USED IN RADIOGRAPHIC SYSTEMS TO:

A. REDUCE THE TUBE VOLTAGE DURING EXPOSURE B. ACHIEVE THE SHORTEST POSSIBLE EXPOSURE TIME

C. MAINTAIN CONSTANT TUBE CURRENT D. MINIMIZE PATIENT DOSE

Q 4: THE FILAMENT VOLTAGE WILL RESULT IN:

A. INCREASED NUMBER OF ELECTRONS IN THE TUBE CURRENT B. HIGHER PHOTON ENERGY OF X-RAYS

C. LONGER EXPOSURE DURATION D. REDUCED SPACE CHARGE AROUND THE FILAMENT

Q 5: WHICH OF THE FOLLOWING CORRECTLY MATCHES THE PARAMETER WITH ITS DIRECT EFFECT?

A. TUBE VOLTAGE (KVP) → DETERMINES ELECTRON NUMBER B. FILAMENT VOLTAGE → DETERMINES X-RAY ENERGY

C. EXPOSURE TIME → DETERMINES PHOTON QUANTITYD. FALLING LOA D → REDUCES ANODE HEATINGCORRECT

Lecture 1 | End-of-lecture MCQ review

Choose one answer for each question. Correct answers are highlighted in green.

1. What accelerates electrons from cathode to anode?

A. Exposure time **B. Tube voltage (kVp) ✓**
C. Filtration D. Anode rotation
E. Collimation

2. At 120 kVp, what is the maximum photon energy?

A. 60 keV B. 100 keV
C. 120 keV ✓ D. 150 keV
E. 240 keV

3. What is the function of the step-up transformer?

A. Lower tube current **B. Increase supply voltage ✓**
C. Rectify AC D. Cool the anode
E. End exposure

4. Which generator has the lowest voltage ripple?

A. Single-phase B. Mechanical timer
C. High-frequency ✓ D. Filament supply
E. Synchronous timer

5. What does mA primarily control?

A. Photon number ✓ B. Maximum photon energy
C. Exposure time D. Anode angle
E. Beam filtration

6. What is 200 mA × 0.25 s?

A. 5 mAs B. 25 mAs
C. 40 mAs **D. 50 mAs ✓**
E. 80 mAs

7. Why use a short exposure time?

A. Increase kVp **B. Reduce motion blur ✓**
C. Increase anode angle D. Create K-shell vacancies
E. Lower filament heat

8. What ends an exposure under AEC?

A. Fixed rotor speed **B. Enough receptor radiation ✓**
C. Filtration change D. Tube cooling
E. kVp increase

9. What generates the electron cloud at the filament?

A. Rectification **B. Thermionic emission ✓**
C. Collimation D. Compton scattering
E. Bremsstrahlung

10. In falling-load operation, tube current:

A. Increases continuously **B. Falls as the tube heats ✓**
C. Stays constant D. Reverses direction
E. Sets photon energy

Any questions?

